

INSPECTION RECORD

IMPORTANT NOTICE: Complete and attach this tag to your extinguisher to maintain safety and your warranty.

Model Number: _____

Serial Number: _____

Canister Date: _____ 20____
(If applicable)

Installation Date: _____ 20____

INSPECTION

Inspection should be performed monthly or more frequently if circumstances warrant. Check the following:

- 1.) The unit should be free of any damage.
- 2.) The nozzle and or hose should be checked to assure it is free of any blockage.
- 3.) The gauge should show the proper charge pressure as indicated by the indicator being within the printed green range.
- 4.) Visually inspect the seal that secures the safety pin in place, and that it is in good condition.
- 5.) Visually inspect that the operating instructions and inspection tags are clearly visible, completely legible and current.

MAINTENANCE

Annual Maintenance is a more complete inspection of the extinguisher and should be done by an authorized professional. Close inspection will reveal the necessity of a hydrostatic test, which is required every five years on water-based extinguishers. **(Note: This is not required on the disposable / recyclable canister type fire extinguishers.)**

AFTER USE

All refillable extinguishers should be immediately recharged. Rechargeable extinguishers shall be serviced by an authorized FireStopper® Distributor. Modular pre-charged canister extinguishers are designed to be serviced directly by the end user as described within these instructions.

Distributed by: See your retailer

INSTALLATION

Install, inspect, maintain and test your fire extinguisher in accordance with the National Fire Protection Association Standard Number 10 labeled "Portable Fire Extinguishers" or its closest intent as applicable.

Your fire extinguisher should be mounted/maintained in a clean, dry area, easily accessible to possible fire hazards, clear of obstructions and if possible near an exit. Mount your extinguisher at a level of 3½ to 5 feet from the floor and out of the reach of young children.

Use the mounting bracket provided with your extinguisher (if applicable) or an approved FireStopper® vehicle bracket (optional) if required. Always fasten to a solid surface using strong screws or fasteners (not included).

Follow the mounting instructions below, particularly in public areas where the extinguisher may become dislodged from the bracket or have objects placed or hung on it.

MOUNTING INSTRUCTIONS

UL specifies that a hanging device must withstand a vertical force equal to five times the weight of the charged extinguisher but not less than one hundred pounds. The bracket should be mounted as follows:

Walls where 2" x 4" studs can be found:

All size extinguishers.

Mount the wall hanger bracket using two number 12 wood screws 1¼" long directly into the stud.

Sheet Rock:

All size extinguishers.

Mount a ¾" thick board to the wall using 3/16" toggle bolts. The extinguisher dimensions should determine the height and width of the board. The board should extend a minimum of two inches past all sides of the extinguisher profile. Mount the wall hanger bracket to the board using two number 10 wood screws one inch in length.

Cinder Block or Concrete:

All size extinguishers.

Mount wall bracket using one ¼" toggle bolt or masonry lead screw expansion anchor and bolt.

Tile Walls:

All size extinguishers.

Mount wall bracket using one ¼" toggle bolt or masonry lead screw expansion anchor. Locate anchor in tile joint.

Steel Posts or Beams:

All size extinguishers.

Special tools and fasteners are required. Have the extinguisher mounted by a professional fire extinguisher service company.

INSPECTION

Inspection should be performed monthly or more frequently if circumstances warrant. Check the following:

- 1.) The unit should be free of any damage.
- 2.) The nozzle and or hose should be checked to assure it is free of any blockage.
- 3.) The gauge should show the proper charge pressure as indicated by the needle being within the printed green range.
- 4.) The seal that secures the safety pin in place should be in tact and in good condition.
- 5.) Inspect that the operating instructions are clearly visible and complete.

IN CASE OF FIRE

1. Have everyone evacuate the area immediately.
2. Call the Fire Department immediately, even if the fire appears to be small. Small fires can quickly become large fires. The Fire Department phone number should be posted at every phone or call 911.

Phone Number _____

3. Use your extinguisher properly, according to the instructions on the nameplate and in this manual. Professionals should fight a large fire. Be prepared to leave the area quickly if the fire cannot be immediately controlled.

OWNERS MANUAL



Hand Held Portable Fire Extinguishers

All FireStopper® Extinguishers are effective on

— Class A B C D & K Fires —

CONTENT:

ENVIRO-SAFE® PFE-FR

Liquid Freeze Resistant Formula
To: -100°F (-73.33°C)

OPERATIONAL LIMIT

From: -100° F (-73.33° C) to 140°F (60°C)

◆ Non Toxic ◆ Non Irritant

◆ Environmentally Safe

◆ 100% RECYCLABLE

20 year Limited Warranty*

*(As applicable by Model)

FireStopper International Limited, ("FireStopper") warrants, all fire extinguishers to be free from defect in material & workmanship for a period of (20) twenty years from date of purchase. During the warranty period, any such defects will be repaired or replaced at the discretion of FireStopper. The original seals must be in place or the warranty is void. This warranty does not cover defects resulting from modification, alteration, abuse and misuse, exposure to corrosive conditions, or improper installation and or maintenance where required. The pressure gage and wearable parts are expressly excluded. DURING THE LIMITED WARRANTY PERIOD, OWNER SHALL AND MUST SERVICE THE EXTINGUISHER ONCE EVERY (2) TWO YEARS. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF FITNESS FOR PURPOSE AND MERCHANTABILITY, ARE LIMITED TO THE TIME PERIODS STATED ABOVE, AND IN NO EVENT WILL FIRESTOPPER OR ANY OF ITS PARTNERS, AFFILIATES, ASSOCIATES, SUBSIDIARIES, DISTRIBUTORS, AGENTS OR EMPLOYEES, BE LIABLE TO INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND.

FireStopper International Limited

Email: info@firestopperinternational.com

Web: www.firestopperintl.com

